









## RVMASWITCH

### I've replaced the RVMasterSwitch in my RV, but it doesn't work?

You need to pair the **RVMasterSwitch** to the **RVMasterNode** before you can use the switch.

The **RVMasterSwitch** is paired to the **RVMasterNode** in four steps:

1. Using the < or > button on the **RVMasterController**, navigate to the 'PA' menu item (Figure 23).



**Figure 23:** Use < or > to navigate to the 'PA' menu item

2. When 'PA' appears on the display, press the RET button to start the pairing process between the **RVMasterSwitch** and **RVMasterNode** (Figure 24)



**Figure 24:** Press RET to start pairing

3. Press any two buttons on the **RVMasterSwitch** at the same time (Figure 25)



**Figure 25:** Press any two buttons on the RVMasterSwitch

4. Press EXT on the **RVMasterController** to accept the pairing of the **RVMasterSwitch** to the **RVMasterNode** (Figure 26)



**Figure 26:** Press EXT to accept pairing