

# RVMASTER

POWERED BY  BM PRO

HELP GUIDE

## RECONFIGURING YOUR RV TO FIX MISSING OPTIONS


## ABOUT


The May 2022 release of the RVMaster App allowed for the configuring of an RV without selecting standard items, which could lead to an incorrectly-configured app.

The August 2022 release of the RVMaster App has corrected this issue. If you have updated your RVMaster App between May and August 2022, you will need to reconfigure it to ensure you have access to all available options.


## RECONFIGURING YOUR RV

To configure your specific RV model to the RVMaster App:


1. Open the RVMaster App.
2. From the app main screen, press the Settings icon. 
3. Press the General Settings bar five times to enter the configuration page.




4. Press Update Existing Options.




5. From the menu, select your model of RV.




6. Select the floor plan.



7. Select any Optional Extras you have, and press **Next**.



8. Enter the Serial Number and press **Confirm**.



The RVMaster App will then restart, and the reconfiguration will display.

POWERING YOUR ADVENTURES