







RVVIEW

The RVView is an easy to use, wall mounted display monitor that shows your RV's vital battery information such as: volts and amps, battery charge and discharge status, as well as the details of your source input for your recreational vehicle's 12V system.

The RVView is permanently wired to the BatteryPlus35 and gives you vital up-to-the-minute data about your RV's current status using a clear backlit display.

KEY FEATURES

-  View system voltage
-  Input and Output Current
-  Battery Charging and Discharging Indicator
-  View Input Power Source – Mains, Solar or Car (Aux)
-  Warning Indicator
-  Shows Battery Charging Status

SPECIFICATIONS

Voltage Measurement Range	8V to 15V
Visual Warning	For BatteryPlus35 output overloading & short circuit
Input Voltage	8V to 15V
Input Current	< 21mA with no backlight
Fault Protection	Reversed Battery Protection (installation)
Operating Temperature	0°C to 50°C
Dimensions	100 x 80 x 15.5mm

