


 **RVMASTER**

HELP GUIDE

**CONFIGURING
YOUR RV TO THE
RVMASTER APP**

RVMASTER




ABOUT

The **RVMaster App** allows for the configuration of your specific RV model. This help guide outlines detailed instructions for configuring your RV to the **RVMaster App**.

CONFIGURING YOUR RV

To configure your specific RV model to the RVMaster App:

1. From the app main screen, press the Settings icon 
2. Press the General Settings bar five times to enter the configuration page.
3. From the menu, select your model of RV.




Figure 1: Selecting the RV model from the RV Configuration screen

4. Select the floor plan.



Figure 2: Selecting the RV floor plan from the RV Configuration screen

5. Select any Optional Extras you have, and press **Next**.




Figure 3: Selecting optional extras from the RV Configuration screen

6. Press **Confirm**.




Figure 4: Confirming the RV configuration from the RV Configuration screen

The **RVMaster App** will then restart, and the new configuration will be displayed



BM PRO

**TEAM
BM PRO
.COM**

BM PRO

821 E. Windsor Ave, Unit 1
Elkhart, IN 46514

support@bipro.zendesk.com

035289 Rev1.0