




# ZERO POINT CALIBRATION SEQUENCE

To perform a zero point calibration on a compatible leveling system:


1. From the App home screen, press the Settings icon .
2. Press **Motor Settings**.
3. Press and hold the **START** button for half a second.




This puts the leveler into zero calibration mode. If active, a status message will display "Calibration Active".



4. Press the direction arrow buttons to move the jacks until the RV is level.



5. Press and hold the SET button for half a second to set the zero point.



The leveler will take a few seconds to calibrate.

When completed, the status will return to "Idle".